






















Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.


01/17/23












14

RIGHT JAMB
(OUTSWING)










15






3-PIECE MULLION
(FIXED TO FIXED)




Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.




01/17/23

















34
SELF-STACK
(INSWING OVER FIXED PANEL)




35
RIGHT JAMB
(FIXED)




36
RIGHT JAMB
(INSWING)



37
RIGHT JAMB
(FIXED PANEL)




39
SILL
(FIXED PANEL)



38
SELF MULLION
(FIXED TO FIXED)


Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

01/17/23



40

3-PIECE MULLION
(FIXED TO FIXED)










41

3-PIECE MULLION
(INSWING TO INSWING)

Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.


01/17/23






Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

01/17/23



52
SELF MULLION
(OUTSWING TO FIXED)



53
SELF MULLION
(FIXED TO INSWING)

Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

01/17/23

