





Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

08/19/19




Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

08/19/19

1
HEAD
(HORIZONTAL SLIDING)


INSECT SCREEN
(OPTIONAL)

2
SILL
(HORIZONTAL SLIDING)







Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.


08/19/19



Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.


08/19/19






16

HEAD
(HORIZONTAL SLIDING)




18

LEFT JAMB
(HORIZONTAL SLIDING)




17


SILL
(HORIZONTAL SLIDING)




19
RIGHT JAMB
(FIXED)




21
SELF-STACK
(FIXED PANEL OVER HORIZONTAL SLIDING)




20
HEAD
(FIXED PANEL)




22
LEFT JAMB
(HORIZONTAL SLIDING)




23
SELF-STACK
(HORIZONTAL SLIDING OVER FIXED PANEL)



24
SILL
(FIXED PANEL)





25
TRUE MUNTIN
(FIXED PANEL TO FIXED PANEL)



26
RIGHT JAMB
(FIXED PANEL)


Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

08/19/19




Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

08/19/19




30

SELF-MULLION
(HORIZONTAL SLIDING TO FIXED)



31

SILL
(FIXED)



32

TRUE MUNTIN
(FIXED)

Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

08/19/19

