








Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

5/9/19



Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

5/9/19









HALF SCALE DETAILS

PAGE 2 OF 10


Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

5/9/19




Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.


5/9/19




12
MEETING RAIL



13
LEFT JAMB
(FIXED)







14
MEETING RAIL



15
RIGHT JAMB


Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

5/9/19




Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.


5/9/19




②①
LEFT JAMB
(FIXED)



②②
MEETING RAIL







②③
TRUE MUNTIN
(FIXED PANEL TO FIXED PANEL)



②④
RIGHT JAMB
(FIXED PANEL)



Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

5/9/19




Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

5/9/19




Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.


5/9/19




32
TRUE
MUNTIN



34
RIGHT JAMB
(FIXED)



33
TRUE
MUNTIN



35
LEFT JAMB

Details shown reflect the most commonly used configurations.
Contact AWM for additional details and/or assistance.

5/9/19

